



Calculate the Real Size of the Glass for Replacement

If you need to fix or replace your broken glass on your window, please measure the size accordingly and add $\frac{7}{8}$ inch to the width and height, which is the actual size of the glass for you to order from us:

Based on the edge of the glazing bead, measure the width and height between the edges, as follows:



For Example, the size you measured is 48x52, then the actual size of the glass to order is $48\frac{7}{8} \times 52\frac{7}{8}$.

Note: This method is for windows manufactured by Value Windows and Doors.